

## Installation Instructions Body Colored Shock Tower Covers



**Step 1:** Identify the drivers and passenger side covers by looking for the "P" and "D" on the underside of the cover.

**Step 2:** Snap the covers in place by lining the fingers on the underside of the cover up with the center hole in the shock tower. Make sure the notched portion of the cover is facing towards the fender. The covers need a pretty good push or rap for the fingers to seat in place.

Questions? We can be reached by e-mail [sales@midwestautogear.com](mailto:sales@midwestautogear.com) or by phone: **262-367-8254**

