

News Bulletin!!

"Wow! CPC's new NXT Generation 2005-08 Hood lift kits are now available in 8 select colors to match * your Mustang's color scheme as well as our original "Natural" aluminum finish."

**Special Note: Colors are matched to factory color chips, colors and finish may vary slightly from the factory finish on your Mustang.*

INSTALLATION INSTRUCTIONS

Installing a NXT Generation Mustang hood lift kit is one of the easiest and most satisfying modifications anyone can do for themselves, and it takes only minutes.

Important Please read entire instructions before attempting to install this kit. This will prevent any missteps that could complicate the process or cause damage to yourself or your Mustang.

1. Raise the hood and secure it with the factory prop rod.
2. Locate the smaller of the two windshield washer hose clips on the passenger side of the hood. This clip conflicts with the hood side lift bracket and must be removed. Unfasten the hose from the clip and remove the clip.
***Note:** This clip is not reusable, and you will not need it for this installation, so it can be cut with a knife or dikes, or pulled out with pliers.
3. Apply a small strip of masking tape to the side of the hood hinge and the side of the hood frame on each side and draw a line to mark existing alignment (hood adjustment).
4. Working on one side at a time, remove the last fender bolt next to the cowl (firewall) and install the lower bracket using the existing factory fender bolt.
***Note:** Brackets are "side specific" and are marked "D" for driver side, "P" for passenger side.
5. Before removing the hood hinge bolts, place a towel or pad between the hood and cowl and covering the fender to protect against damage should the hood slip from your grasp.
6. Holding the hood at the rear corner, remove two hood hinge bolts and position the appropriate (driver or passenger side) upper hood lift bracket over the hinge. Install both hinge bolts "finger tight" and adjust forward or rearward until your marks on the masking tape "line up" again and tighten the hood bolts securely.
7. Repeat steps 4 through 6 on the opposite side.
8. Disengage the prop rod and slowly lower the hood to double check hood alignment and make any readjustments as are required to reestablish a perfect fit.
9. With a helper holding the hood up, install both of the gas struts to the appropriate ball studs, making sure to mount with the cylinder up and the shaft down. This arrangement will guarantee the longest life for your gas struts.

Congratulations, installation is now completed!

****Suggestion** – Remove the factory prop rod and "J" nut, as you will not need them again. It will reduce weight and clutter.

If you have any questions or need assistance, please call our toll free number (888) 225-7669 8:00 a.m. – 4:30 p.m. PST and ask for Tech help.

Important Notice: This kit has been engineered with the appropriate balance to lift a standard factory hood. It may not lift a heavier aftermarket hood and may, over time, bow a light weight aftermarket hood.