

## **Mustang S197 2005-Up Rear Diffuser Installation Manual**

**Components List:**

1 x Rear Diffuser

2 x Long "L" Brackets

6 x M6 Bolts

6 x M6 Washers

6 x M6 Nuts

**Approximate Installation Time:**

1 Hour



**Installation Procedures:**



1. Remove factory nuts shown.



2. Attach long "L" bracket to the open stud using the factory nut. The bottom of the "L" should face towards the rear of the car.



3. Hold the rear of the diffuser over the small lip that protrudes from the rear factory bumper.



4. Drill ¼” holes into the bumper through the 4 existing holes in the rear diffuser.
5. Attach M6 bolts from the outside, and M6 washers and nuts from the inside to secure the rear diffuser to the rear bumper.



6. Attach M6 bolts from the bottom, and M6 washers and nuts from the top to secure the front portion of the diffuser to the “L” brackets.



**Installation is now complete!**